

# OCEAN.TOYS



## The Seahorse Wearable App-Controlled Vibrator

Thank you for purchasing this Ocean Toys product.

By choosing Ocean Toys, you are helping to donate to Marine Conservation Charities. We donate a portion of the sale\* of each product to help to protect our beaches, ecosystems and wildlife.

Our product packaging is fully recyclable and we do not include a printed manual to avoid unnecessary waste and help to reduce our impact on the environment.

All you'll receive in the box is the product and charging cable. Nothing unnecessary. Plain and simple.

<b>Model</b>	<b>SY3210-009</b>
<b>Code</b>	<b>2322</b>
<b>Product</b>	<b>The Seahorse</b> 
<b>QR Code:</b>	



Product Materials	Body safe, super soft liquid silicone
Battery	240 mAh Lithium Battery
Usage Time	Approx 70-100 minutes
Charging Time	Approx 80 minutes
Waterproof	IPX7 Waterproof (Submersible)
Net weight	0.62kg
Size	Approx 113mm x 37mm

All Ocean Toys products are manufactured using Platinum Silicone, the highest grade of silicone, which is a body safe material.

#### Usage information

Looking after your Ocean Toys product correctly will prolong the life of the product. Please follow the safety information below.

- Clean the product before each use. Wash with antibacterial soap and rinse with warm water. Pat dry with a towel.
- Do not use with massage oils or hand creams.
- Do not use silicone-based lubricant as this can damage the silicone surface.
- Do not clean with cleaning products containing alcohol, petroleum or acetone.
- Avoid direct solar radiation and long-term exposure to high temperatures.
- Store the product in a clean, dry, dust-free environment, away from contact with other plastic products.

#### Built-in battery maintenance

- This product contains a built-in rechargeable battery.
- The new battery may take several full charges and discharges before it reaches its optimum level.
- Once the product is fully charged, disconnect the charger. Leaving the product on charge when it is fully charged can reduce the product's battery life.
- The product may gradually lose charge if not used for a while.
- The battery life may be reduced if stored in hot or cold temperatures.

#### Warning

**Do not attempt to remove the battery from the product as it could cause fire or chemical burns. If the product is damaged in any way, discontinue use immediately and dispose of the product correctly in accordance with the local laws and regulations. Where possible, please recycle.**

#### International Certification

Ocean Toys products have passed EU ROHS certification and meet EU CE Directive and WEEE Directive.

Ocean Toys products are "Green" meeting the official safety and environmental protection standard issued by agencies in Europe and North America.

Additional Information: The EU CE Directive and the WEEE Directive are referred to as the "Twin Directives for Environmental Protection" or "Double Green Directives" and are used to restrict hazardous substances in electronic products including lead, cadmium, and mercury. ROHS stands for "Restriction of the Use of Certain Hazardous Substances"; and WEEE stands for "Waste Electrical and Electronic Equipment". Products that meet the standards set out in these two directives can be advertised as "Green Products".

EU CE Directive: Is the collective name of a series of product standards issued by the European Union; enterprises complying with the standard may apply for CE certification mark on their products and labelling. Ocean Toys products surpass the standards set out by these directives and are authorized to use the mark identifying that the products comply with all EU requirements.

## Vibration Patterns

The Dolphin features 10 pre-set vibration patterns. These can be cycled through using a short press of the power button.

Pattern 1 – Low vibration

Pattern 2 – Medium vibration

Pattern 3 – High vibration

Pattern 4 – Short pulse and hold

Pattern 5 – Constant pulse

Pattern 6 – Speeding pulse

Pattern 7 – Long pulse and long hold

Pattern 8 – Building

Pattern 9 – Low high

Pattern 10 - Constant

## App Connection

The Dolphin's functions can be enhanced by using the Love Spouse App on your mobile device.

### Download the Love Spouse App

Ocean Toys are compatible with the Love Spouse app\*\*, available on Google Play and App Store. Please scan the QR Code below to access the download link for your device.



\*\*Please note that Love Spouse is not affiliated with Ocean Toys in any way and you use this app at your own risk. Users are bound by the terms and conditions of Love Spouse, and Ocean Toys is not responsible for the data Love Spouse holds on its users. Ocean Toys is unable to provide help and support with using the App. Users will need to contact Love Spouse directly for this.

Once you have downloaded the Love Spouse App on your device, follow the instructions on screen, then follow the steps below to add your Ocean Toys product to the app.

- 1) Once you have created an account and are logged in, press and hold the power button on your Ocean Toys product to turn it on.
- 2) Switch on Bluetooth on your mobile device or tablet.
- 3) Click “+” in the App, **then scan the QR Code below to add your product.** Or, tap on “enter the device code” at the bottom of the screen and use code **2322** to add the device to the app.



Your product should then be connected to the Love Spouse App, and you can start to explore the patterns and modes available.

## Love Spouse Modes (April 2024)

Within the app, you can explore multiple vibration patterns and functions, including Please note that they may vary, depending on the version of the App being used and the product you are using the App with.

Classic Mode – choose from a number of pre-set patterns.

Game Mode – play games and be rewarded with pleasurable stimulation.

Video Mode – view videos on your device and control your product in one convenient place.

Music Mode – feel the vibrations of your music.

Draw Mode – draw your pleasure on screen.

Shake Mode – shake to vibrate.

Interactive Mode – control your toys with your lover, partner or friends.

## Cleaning

Wash your Ocean Toys product between uses with clean, soapy water or toy cleaner. Air dry or pat dry with a clean towel. Store the product in a cool, ventilated, dust free area, away from direct sunlight.

### Warnings

- 1) Although the product is waterproof, we do not recommend submerging the product in water for long periods of time.
- 2) We recommend the use of water-based lubricants only with this product.
- 3) Store the product in a cool, ventilated, dust free area, away from direct sunlight.
- 4) This product is sold as a novelty only. Stop using the product immediately if you experience discomfort of any sort.

\*£0.50 GBP is donated from the sale of each Ocean Toys product to marine conservation charities.